

# WATCHDOG **NXT**

## Duct Kit: Remote Control Applications





In this application, the duct kit is used with a remote control (W-100) to install the dehumidifier in an adjacent room, such as a mechanical room.

### **Tools:**

- Phillips Head Screwdriver
- N-1204 Duct Kit which includes:
  - (2) Duct Collars (Inlet + Exhaust)
  - (8) Mounting Screws (4 for Inlet, 4 for Exhaust)
- W-100 Remote Control Kit which includes:
  - (1) Remote Control
  - (25') CAT-5 Cable
  - (1) Mounting Bracket
  - (2) Screws to Mount Remote Control to Mounting Bracket
- Screws to attach mounting bracket to wall (not included in W-100)




1. Place duct collar on the inlet and exhaust side of dehumidifier. Secure with 4 screws on each side.





2. Use 10" flex ducting to connect duct collars to supply and return grilles in room you wish to condition. Slide ducting over adapter and secure with tie wrap or clamps.



3. Install the remote control mounting bracket in the conditioned room. This will provide sensor input to dehumidifier in adjacent room. Screw the remote control onto mounting bracket.

